

assembly instructions parallel blade damper

Montage instructies :

1. Cut the side plates (KR50) to the required length.
2. Cut the top and bottom plates from galvansied steel.
3. Assemble a frame of DW duct profiles using also the connector (KR04).
4. Cut the blades (KR110) to the required length making allowance for the blade inserts (KR01).
5. Cut and fit edge seal (KR05) to the blades (KR110).
6. Fit the blade inserts (KR01) onto the blade (KR110).
7. Insert the blade into the frame using the link arm (KR03) and end bearing (KR02).
8. Spindle (KR10) should be fitted into the link arm (KR03).
9. Assemble linkage (KR06) to the link arm (KR03)

